

FireWall Valve LLC

For Fire Protection Valves

UL/FM Wall Indicator Post

Specifications

- Indicates if valve is in open or shut position
- Used to operate a valve installed behind a wall
- With a 12" OD post flange to mount on a wall
- Operated by handwheel
- Can be supplied to open Left or Right
- UL Listed/FM Approved

Field Adjustment

- Remove the Top Section from the top of the Indicator Post assembly
- Reattach the Top Section to the top of the Indicator Post assembly.
- Set the "OPEN" and "SHUT" targets for the appropriate valve size

